

Touch-free Dispenser Refill Instructions



- ◆ Remove perforated section from side and bottom of white refill box. Do not remove plastic refill bag from white box.
- ◆ Pull tube from perforated opening on refill box.
- ◆ Turn the tubing at the top where it connects to the bag refill so that the semi-circle or half moon shape is at the bottom of the tube is towards the back.
- ◆ Hold the refill over a trash can and prime the refill by taking the tube with two hands and squeezing a few times until the air is forced out causing liquid to shoot in a stream. You may here the air pop.
- ◆ If the refill dribbles and does not shoot; try again
- ◆ Open the dispenser at the top by sticking the key in the slots on top pressing down.
- ◆ Once the dispenser is open, take the box and set it in the cradle with one hand and hold it in place while lining up the tube with the center slot.
- ◆ While holding the box, pull the tubing with the other hand down until there is no slack and rest the half moon/semi-circle underneath and against the black motor carriage inside the dispenser.
- ◆ Close the dispenser until you here the prongs on the base click into place on the dispenser cover.
- ◆ Close the dispenser cover. View the sensor on the front bottom left of the dispenser. The light will flash red and green several times and then turn out - the dispenser is ready to dispense.
- ◆ If the light remains red or is blinking red, the dispenser is either loaded incorrectly or not working.
- ◆ If the light remains on or blinking please try reloading the system again.